


### **INSTALLATION INSTRUCTION**



### D70-T

Multi-functional and professional tilt wall mount


For TV panels: 50"-70" Maximum load capacity: 150 lbs / 68.2 kg

VESA: 100x100~600x400mm

#### Kunshan Hongjie Electronics Co., Ltd

Add:58, South of Xinxing Road, Economic Development Zone. Kunshan City, Jiangsu Province, China TEL:86-512-57971777 http://www.nbavmount.com

FAX:86-512-57970776 E-mail: info@nbavmount.com



### **D90-T**

Multi-functional and professional tilt wall mount

For TV panels: 60"-90" Maximum load capacity: 200 lbs / 90.9 kg

VESA: 200x200~800x600mm

We reserve the right to modify or alter instructions. No modification or alteration without formal notice.

## **Contents**

Contents and warning	1/11
Symbols and Tools · · · · · · · · · · · · · · · · · · ·	2/11
D70-T Hardware Package list ·····	3/11
D90–T Hardware Package list ·····	4/11
Installation of wall plate ·····	5/11
Attach TV bracket, select spacers.and scre.w.s.	6/11
Attach TV bracket to wall plate	7/11
TV height and tilt adjustment ······	8/11
Remove TV from the wall plate · · · · · · · · · · · · · · · · · · ·	9/11
D70-T TV Installation VESA hole and Dimensions · · · · · · · · · · · · · · · · · · ·	10/11
D90-T TV Installation VESA hole and Dimensions ······	11/11

#### Warning

Severe personal injury and property damage can result from improper installation or assembly. Read the following warning carefully before beginning.


- If you do not understand the instructions or have any concerns or questions, please contact a qualified local installer.
- Do not install or assemble if the product or hardware is damaged or missing, if you require replacement parts, please contact your local distributor for assistance.
- ●(D70-T) fits most 50"-70" LCD/plasma screen; maximum weight of LCD/plasma screen:150lbs/68.2kg.(D90-T) fits most 60"-90" LCD/plasma screen;maximum weight of LCD/plasma screen:200lbs/90.9kg.
- Do not use this product for anything other than the original design.
- This product contains moving parts, please use with caution.
- The manufacturer disclaims any liability for the modifications, improper installation, or installation over the specified weight range. The manufacturer will not be liable for any damages arising out of the use of, or inability to use, the product.

### Symbols and Tools


### **Symbols**

### Tightening Open-End Wrench By Hand Hand Drill Direction loosening Hex Wrench Remove Adjustment Direction Phillips **OPT** Optional Pencil Star Wrench Screwdriver


### **Tools**



### D70-T、D90-T Hardware Package list




### D90-T Hardware Package list




### 1.Installation of wall plate

- 1.Install wall plate into solid concrete or wood stud.(D90-T)
- A. For Solid concrete installation, please follow 1a-3a.



B.For wood stud Installation, please follow 1b-3b.




### 2. Attach TV bracket, select spacers and screws

1.Install TV to brackets as below shown.


Spacers configuration:

- a. Mount the spacers above TV bracket for Flat panel back to make TV much close to the wall.
- b. Mount the spacers under TV bracket for irregular flat panel back or inset holes or large cables to increase the distance between wall and flat panel.
- Warning: (1)Don't put your hand into bracket to prevent clamping.(2)Make sure the adjustment knobs on brackets are oriented to outside edges.
- 2a.Screws, spacers and washers combination: (A1orB1+E1+2\*F1)or (C1+2\*F1)or (D1+2\*G1)as below shown (D70-T).
- 2b. Screws, spacers and washers combination: (A1+D1+2\*E1) or (B1+2\*E1) or (C1+2\*F1) as below shown (D90-T).



### 3. Attach TV bracket to wall plate


- (1). Hang bracket's up-slot with TV onto wall plate and then push TV bottom along wall plate to lock into the down-slot.
- (2). The brackets could be moved left and right freely.




### 4.TV height and tilt adjustment

(1). Adjust TV height according to below steps to satisfy your viewing requirement.


(2). Fix the viewing angle by loosing and tightening the adjustment knob as below pic.






### Remove TV from the wall plate


(1). Pull down the nylon cord and then pull out the TV bottom a little space from wall, lift your TV to depart from the wall.



### D70-T TV Installation VESA hole and Dimensions

- (1).TV Installation VESA holes.
- (2).TV mount dimensions.





### D90-T TV Installation VESA hole and Dimensions

- (1).TV Installation VESA holes.
- (2).TV mount dimensions.

