

Sit-Stand Workstation Desktop



FC35 Fits Most Displays Size: 22"~35" Max Load: 6.6~19.8lbs (3~9kg) VESA:75×75,100×100mm

Severe personal injury and property damage can result from improper installation or assembly. Severe personal injury and property damage can result from improper installation or ass Read the following warning carefully before beginning.

Products must be installed by professional or installer.

If you do not understand the instructions or have any concerns or questions, please contact a qualified local installer.

Do not install or assemble if the product or hardware is damaged or missing, if you require replacement parts, please contact you local distributor for assistance.

This product fits most 22"-35" LCD / monitor; maximum weight of LCD / monitor:

- This product fits most 22"-35" LCD / monitor; maximum weight of LCD / monitor: 9kg / 19.8lbs.
 Installer-friendly and straight forward.
 For safe installation, the desk you are mounting to must support minimum 3 times the weight of the total load (the mount, the monitor and all accessories weight).
 Do not use this product for other than the original designed.
 This product contain moving parts, please use with caution.
 When installing monitor, please do not damage electrical wiring or power source.
 Installation and routing of monitor cables on the monitor bracket must comply with electricated inclar regulations. electro-technical regulations.
- Importantly, mains- and data-cables must be secured against twisting and squeezing or
- The manufacturer will bear no responsibility to the desk of mounting, or incidental
 or consequential damages arising thereof.
 The manufacturer disclaims any liability for the modifications, improper installation, or
 installation over the specified weight range. The manufacturer will not be liable for any
- damages arising out of the use of, or inability to use, the product.

 This product is designed for indoor used only, use of this product outdoor could lead to product failer and severe personal injury.

 A This product contains a high pressure gas spring, fire and percussion prohibited. Also it is
- strictly prohibited to dismantle without professionals. Please return to the manufacturer or hand over to professional agencies if the product is abandoned. In order to ensure the performance of gas spring, full direction adjustment of the product arm is recommended


. We reserve the right to modify or alter instructions. No modification or alteration without formal notice

Symbols

| mbols | | | |
|-------------|--|-------------|--|
| 96 | Tightening Direction loosening Direction 拧紧方向 拧松方向 | C -5 | +:Torque increased -:Torque reduced ↑ 定点恒力加大 一 定点恒力减小 |
| G | Tightening Direction loosening Direction 拧紧方向 | ±// | +:Torque increased -:Torque reduced + 定点恒力加大 - 定点恒力减小 |
| • | Phillips Screwdriver 螺丝起子 | | By Hand 用手 |
| G G | Open-End Wrench 开口扳手 | | Hex Wrench 六角扳手 |
| | Adjustment 调整 | | Pencil 铅笔 |
| OPT | Optional 可选 | NOTE | Reminder 提示 |
| \triangle | Warning 警告 | | Hand Drill 手电钻 |
| × | Remove 終开 | 1 | Star Wrench 安全扳手 |

FC 35 **Part List** 2x С Α ++4x 4x 2x (M4x12)(M5x12)Ε D 5mm 3mm 4mm


A. Full adjustment after installation




B. Deskmount installation


Note:


Tighten set screw flush with surface.






C. Power and display lines installation






D. Display installation




E. Rotation Restriction



F. Torque adjustment


- "+ ": Torque increase direction shown fig-2
- "- ": Torque decrease direction shown fig-2




Notes: Ensure display weight is within load range.

- If display and keyboard tray can be hovered at any height after display installed. No adjustment needed.
- 2. If display and keyboard tray lift up automatically after display installed, adjust the following: One man hand press down the screen, the other wind set screw at the bottom of upper arm at joint to ' ' direction to reduce torque by using F,5mm. Allen key as shown in Fig-F1 and F2 until display and keyboard tray can be hovered at any point of positions.
- 3. If display and keyboard tray at the lowest position after installation, repeat #2 procedures but winding set screws to '+' direction to increase torque as Fig-F1 and F2 until display and keyboard tray can be hovered at any point of positions.


G. Display height adjustment




H、Tilt angle adjustment




I、Display rotation



J. Keyboard tray extends adjustment



K、Keyboard tray angle adjustment




Inclined adjustment:

①Turn screw anti-clockwise direction using 3mm Allen key D to release. ②Turn screw clockwise direction using 3mm Allen key D to title upright angle.③Turn screw clockwise direction using 3mm Allen to tighten and secure set angle.

Declind adjustment:

①Turn screw anti-clockwise direction using 3mm Allen key D to title down side angle.② Turn screw clockwise direction using 3mm Allen to tighten and secure set angle.

L. Keyboard tray fold up adjustment



TENSION ADJUSTMENT AFTER WALL MOUNT INSTALLED



Do not adjust tension without putting on display.

- 1.Ensure display has been put onto mount.
- 2.Read your display packaging or manual to find out display net weight.
- 3.Ensure display net weight between 6.6~19.8lbs (3~9kg).



Anti-clockwise reduce tension(carry less weight)

clockwise to increase tension(carry more weight)





Add:58, South of Xinxing Road, Economic Development Zone. Kunshan City, Jiangsu Province, China. 215333.

TEL: 86-512-57971777 FAX: 86-512-57970776

www.nbavmount.com